


Demister plug


STEP 2

Remove'IR Sensor Controller' unit by disconnecting wires **4** & **5** from their contacts as shown in the diagram.



STEP 3

Reconnect wires **4** & **5** to the contacts of 'LED Controller' unit as shown in the diagram.



Demister plug

